



If plastic lining is not strong enough please enlarge the holes and use the neoprene bushings and the metric screws!



